

Hip Plumb Cuts

Roof Pitch **Degrees on Chop Saw, Roofing Square**

20°	14.5°
21°	15.0°
22°	16.0°
23°	16.5°
24°	17.5°
25°	18.0°
26°	19.5°
27°	20.0°
28°	20.5°
29°	21.5°
30°	22.0°
31°	23.0°
32°	24.0°
33°	24.5°
34°	25.0°
35°	26.5°
36°	27.0°
37°	28.0°
38°	29.0°
39°	30.0°
40°	30.5°

Roof Pitch **Degrees on Chop Saw, Roofing Square**

41°	31.5°
42°	32.5°
43°	33.5°
44°	34.5°
45°	35.5°
46°	36.0°
47°	37.0°
48°	38.0°
49°	39.0°
50°	40.0°
51°	41.0°
52°	42.0°
53°	43.0°
54°	44.0°
55°	45.5°
56°	46.5°
57°	47.5°
58°	48.5°
59°	49.5°
60°	51.0°

Email info@essential-carpenter-tools.co.uk